












Montageanleitung Kommissionierwagen-Sortierwagen-KM8500

	KM8500	-2	-3
1.		1x	1x
2.	 Ø125	4x	4x
3.	 M10x25	4x	4x
4.	 M10	4x	4x
5.	 Ø200	2x	2x
6.		2x	2x
7.		1x	-
8.		1x	-
9.		1x	2x
10.	 M8x16	4x	4x
11.		-	2x

